



### Notes

Use 3/8" Rubber Grommets in both the Power Cord and Transformer Wire holes so that no wire has direct contact with the chassis.

The 3/8" hole for the tube socket (V1) will be enlarged to 1" using either a punch or step-drill. The 1/8" holes to hold the socket in place will be laid out and drilled according to the written instructions.

The Pilot Light hole will be determined by the light you choose. The size will be on the package. The RS light is 9/32"

Clean up the holes with sandpaper or a deburring tool when you're all done.

SCALE: .1/2" (.50) = 1.00"

